


RB-02 Series Relay Box Dip Switch Settings



3502							
	DIP1	DIP2	DIP3	JP1	JP2	JP3	JP4
3602							
	DIP1	DIP2	DIP3	JP1	JP2	JP3	JP4
6302							
	DIP1	DIP2	DIP3	JP1	JP2	JP3	JP4
6702							
	DIP1	DIP2	DIP3	JP1	JP2	JP3	JP4

Revision History

Date	Revision	Revision History
PENDING	0	Initial Release