

H9-200-09 TETHER BRACKET INSTALLATION - INSTRUCTIONS FOR USE

This document describes how to install the H9-200-09 tether bracket to an Ergon 3 carrier, for use with the Drager Fabius machine models.

Required Tools

- Impact screwdriver
- #2 Phillip's head bit
- 3/16" Allen wrench

Install the Bracket Adapter to the Carrier

Prior to assembling the bracket, attach the bracket adapter to the carrier.

1. Remove the plate on the bottom of the carrier (Figure 1). Use an impact screwdriver with a #2 Phillip's head bit to remove the four corner screws holding the plate in place. Hold the plate up so it does not drop on the floor.




Figure 1. Remove the bottom plate

2. Attach the bracket adapter to the bottom plate (Figure 2). Align the four holes at the top of the adapter with the four holes on the bottom plate. Use a 3/16" Allen wrench to secure the adapter to the plate with four M8 x 50 countersunk screws.




Figure 2. Upper tether bracket adapter

3. Attach the plate to the bottom of the carrier (Figure 3). Align the four corner holes with the holes at the bottom of the carrier. Use an impact driver with a #2 Phillip's head bit to screw the plate to the carrier with four M8 x 20 countersunk screws.




Figure 3. Attach the bottom plate

Assemble the Tether Bracket

1. Slide the Lower Bracket into the Upper Bracket (Figure 4).

2. Loosely screw the knobs into the threaded tubes at the ends of the bracket bars (Figure 4). Tighten the knobs to secure the bracket to the Drager Fabius machine models.




Figure 4. Tether bracket assembly

Revision History

Date	Revision	Revision History
01/10/2018	0	Initial Release

Distributed by:

US - SKYTRON
5085 Corporate Exchange Blvd. S.E.
Grand Rapids, MI 49512 (616) 656-2900
www.skytron.us

Manufactured by:

Accuform Industries Inc.
1701 Broadway, N.W.
Grand Rapids, MI 49504

